


User Manual

FMJ-GROUP

Model: FMJ-F38Pro

REV: 21/09/25



CaiZhuang Town,Wei Shi County,KiaFeng City
,HeNan Province.China 475000
P: (86) 18537382691
www.fumeijinggroup.com

Introduction

Dear Customer:

Congratulations on the purchase of your new **FMJ-F38Pro** Carpet & Upholstery Spotter.

As technology continues to develop you can work confidently knowing that both FMJ-Group and its employees are equally dedicated to developing with the industry and its advances.

Like any other piece of machinery or technology, the FMJ-Group also requires the proper maintenance and care to keep the product working over extended use. Neglecting your machine, abusing it or not operating it properly can void its warranty and prevent the machine from performing to the quality and standard you'd expect out of the FMJ-Group line.

If you have any warranty concerns or questions, please review this manual thoroughly or do not hesitate to contact your distributor. If there are questions regarding maintenance, replacement, or ordering parts please contact an authorized FMJ-Group Service Center. Visit www.fumeijinggroup.com to find your nearest Service Center.

Before using your FMJ-Group product, please read this manual thoroughly.

Sincerely,

FMJ-Group Customer Care Dept.

Table Of Contents

Important Safety Information	4
1 At a Glance	6
1.1 - Technical Specifications	6
1.2 - Included with the FMJ-GROUP.....	6
1.3 - FMJ-F38Pro Front View	7
1.4 - FMJ-F38Pro Rear View.....	8
1.5 - Switch Plate	9
2 Machine Operation	10
2.1 - Installing The Cable of Touch Panel &Open The Valve	10
2.2 - Connecting Hoses	10
2.3 - Installing The Filter Bag	11
2.4 - Connecting Hoses & Cleaning Tools	11
2.5 - Installing the double cable to different rooms	12
2.6 - Filling The Solution Tank	13
2.7 - Operating the FMJ-F38Pro	13
2.8 - How to judge whether its powered on	14
2.9 - How to clean with upholstery cleaning tools	15
2.10 - Emptying the Solution & Recovery Tanks	16
3 Machine Maintenance	17
3.1 - Filter Maintenance	17
3.2 - System Maintainer	17
4 Available Accessories	18
5 Troubleshooting	19

Important Safety Information

Grounding Instructions

This machine must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electrical shock. This machine is equipped with double cords having an equipment-grounding conductor and

grounding plug. The plug must be plugged into an appropriate outlet that is properly installed in accordance with all local code and ordinances. Do not remove ground pin; if missing, replace plug before use.



Improper installation of the equipment-grounding conductor can result in a risk of electric shock. Be sure to check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. If the plug will not fit in the outlet do not modify either the plug nor the machine's cord, instead have a proper outlet installed by a qualified technician.

This machine is for use on a nominal 120-volt circuit and with a grounding plug similar to the one in Figure 1 below. If a proper outlet is not available, follow the illustrations of Figure 2 & 3 to install a temporary-grounding plug. This temporary work-around should be used only until a proper outlet (Figure 1) can be installed by a qualified electrician. When and if this type of adapter is employed, screw the adapter's extended tab into place with a metal screw. However, grounding adapters are not approved for use in Canada.

Again, be sure to check the grounding pin for damages and replace if necessary.

The Green, or Green-Yellow, wire in the cord is the grounding wire. When replacing a plug, this wire must be attached to only the grounding pin.

DO NOT use extension cords.

Please Note for America use only.




Figure 1

Figure 2

Figure 3

Parts and Service

Please contact a FMJ-Group service personnel or FMJ-Group authorized Service Center using FMJ-Group original replacement parts and accessories for repairs are needing to be performed. When and if calling FMJ-Group for support, please have your Model available for faster assistance.

Name Plate

The Model is located on the lower half of the back of the machine near the Leakage protector and will be required for ordering replacement parts. You can use the space provided on the front of this manual to note down both for future referencing.

Unpacking the Machine

When your new machine is delivered, please carefully inspect both the shipping carton and the machine for damages. If damage is evident, save both the shipping carton and machine so that the delivering carrier can inspect it. Contact the carrier immediately to file a freight claim if there has been any damage.

Caution and Warnings

Symbols

FMJ-Group uses the symbols below to signal potentially dangerous conditions. Always read this information carefully and take the necessary steps to protect personnel and property.



Is used to warn of immediate hazards that will cause severe personal injury or death.



Is used to call attention to a situation that could cause severe personal injury.



Is used to call attention to a situation that could cause minor personal injury or damage to the machine or other property. When using an electrical appliance, basic precautions should always be followed, including the follow-

Important Safety Information

ing: Read all instructions before using this machine. This product is intended for commercial use only.

To reduce the risk of fire, electrical shock, or injury:

1. Read all instructions before using equipment.
2. Use only as described in this manual. Use only manufacturer's recommended attachments.
3. Always unplug power cord from electrical outlet before attempting any adjustments or repairs.
4. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
5. Do not pull or carry by cord. Do not close a door on cord or pull cord around sharp edges or corners.
6. Do not run appliance over cord. Keep cord away from heated surfaces.
7. Do not use with damaged cord or plug. If cord is damaged, repair immediately.
8. Do not use outdoors or on wet surfaces and/or standing water.
9. Always unplug or disconnect from power supply when not in use.
10. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
11. Do not use in areas where flammable or combustible material may be present.
12. Do not leave the unit exposed to harsh weather elements. Temperatures below freezing may damage components and void warranty.
13. Use only the appropriate handles to move and lift unit. Do not use any other parts of this machine for this purpose.
14. Do not pull on hoses in order to move the unit. Only use the appropriate handles.
15. Keep hair, loose clothing, fingers, and all parts of the body away from all openings and moving parts.
16. Use extra care when using on stairs.
17. To reduce the risk of fire or electric shock, do not use this machine with a solid-state speed control device.

18. The voltage and frequency indicated on the name plate must correspond to the wall receptacle supply voltage.

19. When cleaning and servicing the machine, local or national regulations may apply to the safe disposal of liquids which may contain: chemicals, grease, oil, acid, alkalies, or other dangerous liquids.

20. Do not leave operating unattended.

1 - At a Glance


1.1 - Technical Specifications

Solution Tank	4 Gallons
Recovery Tank	4 Gallons
Vacuum	Single 3-Stage
CFM	100
Water Lift	130"
Pump PSI	170
Pump GPM	1.5(5.5L/min)
Heater	2,400 watt, 210°F max.
Power Consumption	1x16.5A @ 115V 1x14.5A @ 115V
Machine Weight	60 lbs.
Machine Dimensions	Without handle: 23.6" x 17" x 24.4"
Power Cord	Dual 25' 12/3

1.2 - Included with the FMJ-F38Pro



29' x 1.5 Vacuum Hose




Upholstery Tool




29" Solution Hose



2x 12AwgDouble Cables




Filter Bag



Connect the water hose

1.3 - FMJ-F38Pro Front View



1.Easy-Push Handle

2.Recovery Tank

3.Recovery Tank Lid

4.Touch Screen

5.Solution Tank

6. Suction Inlet


7. Quick brass quick connect

8. 3 "Wheels

9. 10" Wheels

1 - At a Glance

1.4 - FMJ-F38Pro Rear View



10.Recovery Tank Drain Hose

11.Solution tank opening


12.Solution tank water outlet

13.Solution Pump Inlet

14.Power Cable Quick Conneter

15.Touch Panel Quick Connector

16.Butterfly lock



1. Vacuum Switch

Activates the vacuum motor.

2. Pump Switch

Activates the solution pump.

3. Heater Switch

Activates the heater.

4. Temp display

Real-time display of heating temperature and display of set temperature.

Temp display




5. Temp Upper/Dwon


The set temperature can be increased or decreased by touching the up and down buttons.

2 - Machine Operation


2.1 - Installing the cable of Touch Panel/open the valve



Installing the cable of Touch Panel






Valve closed






Valve Open

2.2 - Connecting Hoses







2 - Machine Operation

2.3 - Installing The Filter bag



2.4 - Connecting Hoses & Cleaning Tools




CAUTION Use only low foam or non foaming detergent or shampoo. Damage due to excessive foam will void warranty.




CAUTION Empty the vacuum tank any time you refill the solution tank in order to prevent vacuum tank overfilling.

2 - Machine Operation


2.5- Installing the double Cable to different Rooms



Family Room A



Family Room B




Power Cable
for Heater

Power Cable for
Pump & Vacuum





Hotel Room A



Hotel Room B

2 - Machine Operation


2.6 - Filling the Solution Tank



Bucket With spout is recommended

The solution tank can be filled up via the faucet fill hose or from a bucket via the opening.

2.7 - Operating the FMJ-F38Pro



1. Adjust the knob to the proper pressure

2. start the water pump
(Be sure to connect the steam hose before starting the water pump switch)

3. start the vacuum motor

Switching On The Unit


In order to avoid vapor locking the unit, use the following procedure to switch on the components:

1. Turn pump switch on.
2. Pull the lever on the cleaning tool to release air in the line. Hold lever until a steady flow of water comes out of the wand.
3. Once pump is primed and there is pressure in the solution line, turn on heater switch and wait a few minutes for water to heat up.
4. Once water is heated, turn on vacuum and begin cleaning.


Note: When cleaning upholstery, always check manufacturer's cleaning instructions.

2 - Machine Operation


2.8 - How to judge whether it's powered on




1. Activate The Power




2. Touch the heating switch




3. Iconv keep flashing after
Activate Heating



cooling fan



Heater Cable





Touch Panel
Vacuum & Pump Cord

Test Button

1. The heating cannot be started. Please check whether the button is started and whether the leakage protector is turned off.
2. Before the machine works, check whether the cooling fan is running. You can hear the sound of the fan running, so you can judge whether it is powered on! Machine operation must ensure good operation of the cooling fan. If the fan is damaged, please stop working and replace it in time.
3. Please manually press the test button in the upper right corner of the two leakage protectors, press the small square button, and the leakage protector trips, indicating that the power is in good condition. If it does not trip, the wall is not electrified!
4. Please be sure to connect the matching power cord to the wall, and do not use the plug row with substandard power!

2 - Machine Operation

2.9 How to clean with upholstery cleaning tools




Cleaning Procedure

For best results when extracting, do one wet pass followed by two dry passes. This ensures you're not over-soaking the material and keeps water temperature higher. The solution pump will only turn on when there is a pressure demand (e.g., while spraying with cleaning tool, or right at startup). If the pump is continuously running or pulsing, it does not necessarily mean that it is defective. If the pump is not producing the correct pressure and flow, see the Troubleshooting section of this manual.


2 - Machine Operation

2.10 - Emptying the Solution & Recovery Tanks


Option One: Emptying the Solution Tank




1.Emptying the Solution




2.Find the cuffs



3.remove cuffs clockwise




5.The Vacuum hose extends into the solution tank to suck up the clean water




4.To clean vacuum hose with clean water

Option Two: Emptying the Solution Tank



Turn Off The Power



Release hot water to cold water

3 - Machine Maintenance

In order to keep the FMJ-GROUP running smoothly and reduce the risk of damage to the machine and subsequent downtime, Mytee recommends following the maintenance schedule below:

Maintenance Item	Daily	Weekly
Clean and inspect tanks.	X	
Clean and inspect hoses.	X	
Check and clean internal filters.	X	
Check power supply cable.	X	
Clean machine with all-purpose cleaner and cloth.	X	
Check spray nozzles.	X	
Flush solution system with Mytee System Maintainer.		X
Inspect vacuum hoses for holes and loose cuffs.		X
Inspect spray pattern for clogging. If clogged, remove spray tips and soak them in a recommended liquid neutralizer for up to six hours. To remove spray tip, twist spray tip body counter-clockwise.		X
Lubricate wheels with water resistant oil.		X
Inspect machine for water leaks and loose hardware.		X

3. Turn on the Extractor's pump and run the System Maintainer solution through the system and into a bucket or receptacle until you have a solid stream.
4. Let sit for about 5 minutes while the System Maintainer solution does its job inside your Extractor.
5. Finish running the rest of the solution through the system.
6. Run clean water through the system to flush out any remaining System Maintainer. ♦



CAUTION Do not tamper with the set screw on the pump pressure switch. This can damage the pressure switch.

3.1 - Filter Maintenance

The Mytee Lite™ has a small filter on the top of the vacuum stack in the recovery tank. This filter should be checked and cleaned after each use. ♦


3.2 - System Maintainer

Regular flushing of the solution system with FMJ-GROUP System Maintainer keeps your extractor running efficiently by removing hard water scaling that builds up in the system


How to use System Maintainer:

1. Thoroughly mix System Maintainer with warm water at a 1:1 ratio in a separate container. Pour into your Extractor's solution tank.
2. Connect a cleaning tool (upholstery tool, wand, etc.) and remove the jet(s) in order to prevent clogging from dislodged mineral build-up.


4 - Available Accessories



Upholstery Cleaning Tool



Upholstery Wand Tool



8L Electric Sprayer



10" Jet Carpet Cleaning Wand

5 - Troubleshooting

Issue	Possible Cause	Solution
Machine is not turning on.	Power cord unplugged.	Plug the power cord into a grounded 20 amp outlet.
	Circuit breaker tripped in building Or machine.	Reset breaker in building.
	Faulty switch or power cord.	Contact a FMJ-Group Service Center.
Poor solution flow.	Jet is clogged.	Unclog the jet by removing and soaking in a vinegar and water solution. Scrub with a soft brush. Repeat if necessary.
	Blockage or clog in solution line.	Run System Maintainer through machine.
	Leak in solution line between pump and cleaning tool.	Find leak and repair or replace hose if necessary.
Pump continuously runs/ pulses without producing correct pressure/ flow.	Pump switch failure. This can be caused by various issues: <ul style="list-style-type: none"> • Nozzle tip clogged or too small, causing rapid switch cycling. • Check valve failure between pump and heater causing hot water to return to pump and damage switch. • Pump inlet port is cracked causing pump to suck in air. • Damaged pump switch housing. 	Contact a FMJ-GROUP Service Center
	Vapor lock from turning on heater before pump.	Turn off the heater and allow the machine to cool completely. After machine has cooled, follow the machine startup procedure in section 2.7 of this manual.
Vacuum/pump not turning on.	Bad power switch.	Check power switch by transferring wires from the switch in question to another switch. See if that switch turns on the component in question. Replace switch if necessary.
Vacuum not producing suction.	Vacuum tank is full.	Empty vacuum tank.
	Vacuum hose blockage.	Check for blockages in vacuum hoses inside and outside machine.
Blows water out exhaust.	Foam building up inside vacuum tank.	Use a defoaming solution in vacuum tank or use low foam or non foaming detergent/shampoo.
Water is not getting hot.	Touch screen heating button is off Circuit breaker tripped behind the machine	Turn on the heating switch on the touch panel Turn on the circuit breaker

NOTES

